

# INSTALLATION UV2000

**J.A. PLAST®**  
Completing every roof



Indhold: 1 skabelon, 1 ring, 1 net.  
*Content: 1 template, 1 ring, 1 mesh.*



Markér rundt om skabelonen.  
*Mark around the template.*



Skær hul ud i undertaget.  
*Cut a hole in the underlay.*



Åbn ringen og placer den i undertaget.  
*Open the ring and place it in the hole.*

# INSTALLATION UV2000

**J.A. PLAST®**  
Completing every roof



Klem og luk ringen omkring undertaget.  
*Press and close the ring tightly around the underlay.*



Træk ringens indre kant opad, så vand ledes uden om hullet.  
*Pull the inner edge of the ring upwards to divert water away from the hole.*



Klik nettet fast over ringen.  
*Click the mesh into place over the ring.*



Installeret.  
*Installed.*